



Couture

Applique Petit/Grand
Wall lamp Small/Large

Emmanuelle Legavre

Notice Utilisateur
User's Manual





Lisez attentivement :

Installation : Avant toute utilisation, il convient de s'assurer que la tension d'alimentation a été coupée.

Read these terms carefully:

Installation: Switch off power supply before installing the product.

ATTENTION!

La sûreté de cet appareil est garantie uniquement si l'on respecte ces instructions, soit en phase d'installation, soit pendant l'utilisation. Il faut donc les conserver.

Avertissements :

L'appareil ne peut être modifié ou altéré de quelque manière que ce soit, toute modification peut compromettre la sécurité de celui-ci en le rendant dangereux. Designheure décline toute responsabilité pour les produits modifiés.

Si le cordon d'alimentation externe est endommagé, il doit être remplacé par Designheure ou par une personne habilitée afin d'éviter tout danger.

WARNING!

The safety of this appliance is guaranteed only in case of following these instructions, either during the installation phase or during use. Therefore it is essential to keep them for further reference.

Caution:

The device is not allowed to be altered or modified in any way. Unauthorized alterations might compromise safety of the device, making it dangerous. Designheure declines any responsibility for modified products.

If the external supply cord is damaged, it must be replaced by Designheure or qualified personnel only, in order to avoid any danger.

DONNEES TECHNIQUES - Sources

La chaleur dégagée par une ampoule reflète sa consommation en énergie. Privilégiez les ampoules LED.

TECHNICAL DATA - Sources

The heat released by a bulb reflects its energy consumption. It is recommended to use LED bulbs.

Instructions pour le nettoyage:

Au préalable, veuillez à couper la tension d'alimentation de votre luminaire. Les opérations de nettoyage concernent principalement l'abat jour. Pour le nettoyage de l'abat jour, utiliser exclusivement un chiffon doux.

Cleaning instructions:

Make sure don't forget to switch off the main supply. Cleaning phases should mainly concern the lampshade. Use only a soft cloth for cleaning the lamp.



E 27
E 26



850°
~


IP
20

FRANCE

	Applique Petit Couture/Small	Applique Grand Couture/Large
Abat-jour Lampshade	L. 32 x l. 14 x H. 17 cm	L. 50 x l. 18 x H. 25 cm
Dimensions Dimensions	L. 32 x l. 19 x H. 26 cm	L. 50 x l. 21 x H. 32 cm
Tension	220/240V 50-60Hz 100/127V 60hz	220/240V 50-60Hz 100/127V 60hz
Ampoule conseillée Recommended bulb	LED Max 40 W maxi Ø 60 mm H. 110 mm Max Ø 60 mm H. 110 mm Non fournie/Not included	LED Max 60 W Maxi Ø 70 mm Max Ø 70 mm Non fournie/Not included
Douille/Socket	E27/E26	E27/E26
Coloris Colors	• Blanc/Noir - Fil jaune clair/ White/Black - Light yellow cord • Rose pâle/Noir - Fil chevrons noir - Blanc/Light pink/Black - Black-white Zick Zack cord • Blanc/Pied-de-Poule - Fil noir/White/Houndstooth print - Black cord	• Blanc/Noir - Fil jaune clair/ White/Black - Light yellow cord • Rose pâle/Noir - Fil chevrons noir - Blanc/Light pink/Black - Black-white Zick Zack cord • Blanc/Pied-de-Poule - Fil noir/ White/Houndstooth print - Black cord
Poids Weight	Net/Net kg: 0,660 Brut/Gross kg: 1	Net/Net kg: 0,900 Brut/Gross kg: 1,9
Colisage Packing	Nbre/Nber: 1 Vol.m³: 0,020	Nbre/Nber: 1 Vol.m³: 0,068
Certification Certificate	CE / EAC / ETL	CE / EAC / ETL
Résistance Resistance	Résistance au fil incandescent de 850 à 960°C/Resistance to incandescent wire 850 - 960 °C	Résistance au fil incandescent de 850 à 960°C/Resistance to incandescent wire 850 - 960 °C

Fiche produit


Product information




- Abat-jour/Lampshade - (1) (a) - Vis/Screw Ø 3,5x25mm x 2
 Patère d'alimentation centrale/Supply ceiling plate - (2) (b) - Chevilles/Plastic dowel Ø 5x25mm x 2
 Etrier/Ceiling fixing bracket - (3) (c) - Vis latérales/Side screws
 Bague/Retaining ring - (4) (d) - Bornier/Connecting block

Instructions de montage/Assembling instructions

- ① Dévisser l'étrier ⁽³⁾ de la patère d'alimentation centrale ⁽²⁾. Le système d'encoche ne nécessite pas de dévisser totalement les 2 vis qui resteront sur l'étrier. Fixer l'étrier au mur par les 2 points de fixations à l'aide des vis ^(a) et des chevilles ^(b) fournies.
 - ② Connecter les fils sur le bornier fourni ^(d), puis revisser la patère d'alimentation centrale à l'étrier à l'aide des 2 vis latérales ^(c).
 - ③ Au préalable, dévisser la bague ⁽⁴⁾ sur la douille et placer l'abat-jour ⁽¹⁾ sur le tube, visser la bague sur la lyre.
 - ④ Visser l'ampoule (non fournie) sur la douille.
- ① Unscrew the ceiling fixing bracket ⁽³⁾ from the supply ceiling plate ⁽²⁾. The notch system does not require completely unscrew the 2 screws that remain on the ceiling fixing bracket. Fix the ceiling fixing bracket to the wall by 2 mounting bolts with the help of the screw ^(a) and the plastic dowel ^(b) included.
 - ② Connect the wire to the connecting block ^(d) included and screw the supply ceiling plate to the ceiling fixing bracket with 2 side screws included ^(c).
 - ③ First, unscrew the plastic retaining ring ⁽⁴⁾ from the socket and put the lampshade ⁽¹⁾ on the tube and screw the plastic retaining ring onto the bulb holder socket.
 - ④ Screw the bulb (not included) into the socket.








- Abat-jour/Lampshade - (1) (a) - Vis/Screw Ø 8x30mm x 2
 Patère d'alimentation centrale/Supply ceiling plate - (2) (b) - Chevilles/Plastic dowel Ø 8x30mm x 2
 Etrier/Ceiling fixing bracket - (3) (c) - Vis latérales/Side screws
 Bague/Retaining ring - (4) (d) - Fil de terre/Ground wire

Instructions de montage/Assembling instructions

- ① Dévisser l'étrier ⁽³⁾ de la patère d'alimentation centrale ⁽²⁾. Le système d'encoche ne nécessite pas de dévisser totalement les 2 vis qui resteront sur l'étrier. Fixer l'étrier au mur par les 2 points de fixations à l'aide des vis ^(a) et des chevilles ^(b) fournies.
 - ② Raccorder respectivement la phase (fil noir) et le neutre (fil blanc) au réseau électrique. Raccorder le fil de terre ^(d). Revisser la patère d'alimentation centrale à l'étrier à l'aide des 2 vis latérales ^(c).
 - ③ Au préalable, dévisser la bague ⁽⁴⁾ sur la douille et placer l'abat-jour ⁽¹⁾ sur le tube, visser la bague sur la lyre.
 - ④ Visser l'ampoule (non fournie) sur la douille.
- ① Unscrew the ceiling fixing bracket ⁽³⁾ from the supply ceiling plate ⁽²⁾. The notch system does not require completely unscrew the 2 screws that remain on the ceiling fixing bracket. Fix the ceiling fixing bracket to the wall by 2 mounting bolts with the help of the screw ^(a) and the plastic dowel ^(b) included.
 - ② Connect respectively phase (black wire) and neutral (white wire) to the electric power. Connect the ground wire ^(d). Screw the supply ceiling plate to the ceiling fixing bracket with 2 side screws included ^(c).
 - ③ First, unscrew the plastic retaining ring ⁽⁴⁾ from the socket and put the lampshade ⁽¹⁾ on the tube and screw the plastic retaining ring onto the bulb holder socket.
 - ④ Screw the bulb (not included) into the socket.







designheure

✉ contact@designheure.com
@ www.designheure.com